

Omega[®]

CT-20

Electronic Enlarging Timer

Instructions



IMPORTANT SAFEGUARDS

When using your Omega Photographic products, basic safety precautions should always be taken, including the following:

1. Read and understand all instructions provided with this product.
2. Close supervision is necessary when this product is used by or near children. Do not leave it unattended while it is plugged into an outlet.
3. Avoid touching the lamp area of enlargers or other hot parts as it may cause burns.
4. Do not operate this product if the power supply cord has been damaged or if the product has been dropped or damaged. Have it checked out and repaired if necessary by qualified service men before using.
5. Route the power supply cord away from hot areas. Do not let the cord hang over a counter edge or across an open area where people pass.
6. If an extension cord is necessary, use one with a suitable rating. Cords rated for less amperage than the product may overheat. Route the extension cord away from open areas where it may be tripped over or pulled.
7. Always unplug the product after use. Grasp the plug and firmly pull from the outlet to disconnect. Never yank the cord from the outlet.
8. Allow the product to cool to room temperature before storing. Wrap the power cord loosely around the product.
9. Do not immerse this product in water or other liquids.
10. To avoid electric shocks, do not attempt to disassemble or repair this product. Always have it serviced by qualified servicemen when necessary.

Incorrect reassembly can cause electric shock hazards.

SAVE THESE INSTRUCTIONS

The text of these safeguards is prescribed by Underwriters Laboratories to be included in this instruction sheet for U.L. listed products.

Operating Controls and Features:

- 1. Rotary Time Switches**
Set desired exposure time.
- 2. Function Switch**
Selects FOCUS/OFF-RESET/PRINT modes.
- 3. Range Switch**
Sets desired timing range: .1-9.9, or 1-99 seconds.
- 4. Expose Switch**
Activates timing sequence.
- 5. Footswitch Outlet**
For optional accessory footswitch (Cat. No. 461-060).
- 6. Safelight Outlet**
Handles safelights up to 100W Tungsten.



